

RING NUT WRENCH

YFM200 and YFM250 ATV applications.
35-8544 YM-1391



35-8521 Two piece set



35-8544

MIDDLE DRIVE SHAFT NUT WRENCH

46mm, 12 point socket wrench. Use to remove the middle driveshaft nut on XJ650/750 engines.
35-8456 YM-4045-A



35-8456

55MM OFFSET WRENCH

XV Virago series, XVZ12/XVZ13 Venture & Venture Royale and V-Max. Sold each.
35-8528 YM-4054



35-8528

FINAL DRIVE COLLAR, BEARING & SEAL REMOVER/INSTALLER

All Yamaha shaft drive applications. Consists of two tools: Push Tool-1 for removing and Push Tool-2 for installation.
35-8521 YM-1255

MIDDLE GEAR BEARING RETAINER

Removal and installation tool for ATV applications. YFM350FX/FW & YFM600FWA.
35-8550 YM-04129



35-8550

MIDDLE DRIVE GEAR LASH TOOL


All Yamaha Street and ATV shaft drive applications. (except XV, XJ, XZ series)
35-8520 YM-1231



35-8520

MIDDLE GEAR BACKLASH

ATV applications, YFM200.
35-8545 YM-1393



35-8545

UNIVERSAL JOINT HOLDER SET

XV Virago series, XVZ12/XVZ13 Venture & Venture Royale and VMX12 V-Max.
35-8530 YM-4062



35-8530

PINION GEAR CLAMP

ATV applications. YFM350FX/FW & YFM600.
35-8551 YM-04129



35-8551

GEAR HOLDER

Final drive gear holder for XVZ12/XVZ13 Venture & Venture Royale and V-Max.
35-8518 YM-1229



35-8518

HEX WRENCHES

35-8542 27mm YM-1363
35-8543 32mm YM-1364



35-8543

35-8542

UNIVERSAL JOINT HOLDER

XZ550 Vision series and YFM350 ATV.
35-8539 YM-33214



35-8539

PINION REMOVER ADAPTER

XJ650/XJ750 & XZ550 Vision.
35-8525 YM-1277



35-8525

FRAME SPANNER SOCKET

YZF-R6, XV1700. Sold each.
35-8574 YM-01471



35-8574

DIAL INDICATOR GAUGE & MAGNETIC BASE STAND

35-8421	Dial Indicator Gauge with Magnetic Base Stand
35-8428	2-1/4" Dial Indicator Gauge only, 0" - 2-1/4" range in .001" increment .
35-8438	Magnetic Base Stand only



DRIVE SHAFT PULLER

XS1100 applications. Must use with slide hammer
35-8526 YM-4012



35-8526