



35-5114



35-5138

EXHAUST STUD DRILL PLATE

Designed to guide and align bit in order to drill out broken exhaust studs. A follow up with a tap is all that is needed to clean up threaded hole. This tool can be used with motor in the frame in most cases. For use on Big Twin 1984-present, Buell® 1987-present, Sportster® 1987-present. (Note: Includes Twin Cam 88™ and all aftermarket heads.)
35-5138

TWIN CAM WRISTPIN REMOVER

This tool cuts the time it takes to remove wrist pins and can be used easily by one person. Use on all models including Twin Cam 88™)
35-5114

ROD HOLDER TOOL

Use to keep connecting rods in place while reaming or honing the wrist pin bushings. Works well with JIMS® Tool No. 1051, 95970-32C wrist pin bushing tools and JIMS® No.17261-1, 17261-2, 17621-3 wrist pin bushing reamers. Use on all Twins, Buell® Blast, Twin Cam 88™ A and B.
35-5150

CRANKSHAFT BEARING INSTALLER & REMOVER

Designed to protect expensive engine cases by using a specially designed support block to remove or install cam side crankshaft bearing. Use on 2000-present Twin Cam 88™ "Beta" Softails®. (Note: Use assembly lube on case and bearings during installation)
35-5139



35-5139



35-5150

HARD CAP

Use to protect sprocket shaft when using JIMS® tool No. 1047-TP or a press. Big Twin 1955-present, Twin Cam 88™, aftermarket and S & S® motors.
35-5381 Main Body

INNER CAM BEARING INSTALLER

This tool will install the two inner cam needle bearings on all Twin Cam88™ motors while aligning the shaft bores for a precision press fit.
35-5116

FOUR SPEED TRANSMISSION

RACE LAPPING TOOL

Use to line lap main race on the same centerline as the mainshaft ball bearing after installing new case race or fitting oversized rollers. This tool can be driven by a low speed drill motor from the ball bearing side. Use on Big Twin 1937-Early 1977.
35-5192




35-5116



35-5381

TRANSMISSION GEAR SPACING TOOL

Use to align main and countershafts when checking proper gear spacing. Sportster® 1986-90 and Buell® 1987-90
35-5226



35-5226



35-5192

PINION RACE TOOL

Designed to remove and install pinion race in all H-D® big twin, single-cam models 1955 or later. Will not work on twin-cam models.
35-2271 Pinion Race Tool

